



CONVERTIBLE CHAIR



Total Pieces	6
Squares	6
Triangles	0
Difficulty Level	Medium

Special Note: If you prefer, remove the top cushion to lower the seating height of the chair. This may be more appropriate for younger children. Aerobloks™ is designed to enhance imaginary play and is not meant to be used as actual children's furniture.




SIMPLY FOLLOW THESE STEPS

THE CHAIR FRAME

1. Connect three side blocks to the center seat block through second slit openings (as shown).
2. Be sure to connect the bottom edges of the side blocks to the top edges of the seat block.

HINT: Do the easiest connection per block first. Then, go to the other side of each side block and connect the remaining connectors.



COMPLETING THE CHAIR FRAME

1. Lift the seat block straight up, the attached side blocks will fold inwards naturally to form an inverted chair.
2. Flip the chair frame over, push and connect the side blocks together, remember to use the second slits.



ADDITIONAL CHAIR CUSHIONS

1. Connect two squares through the first slit opening, only along the bottom edge, to form additional cushions (as shown).
2. Now connect the base cushion to the additional cushions through the first slit and only along the top edge of the base cushion. Attaching only one edge creates a hinge effect which allows the extended cushions to fold in and pull out.



PUTTING IT TOGETHER

1. Fold the extended cushions into the chair frame.
2. You've just made a convertible chair! Great job!!
3. Pull the top cushion in and out to form a chair or a sleeper.